




KitchenAid Professional 600 Gear Housing Cover Replacement

To access the Bevel and Worm gear you need to remove this housing cover.

Written By: Luke





TOOLS:

- [Phillips #2 Screwdriver](#) (1)
-

Step 1 — Top Cover



- Take out the screw which holds on the silver band using a Phillips #2 screwdriver.
- Remove the silver band.

Step 2




- Remove the four Phillips #2 screws located around the mixer where the band was removed.
- ⓘ This picture only shows two of the screw that you need to remove. The other two are on the exact opposite side of the mixer.

Step 3




- Remove the top of the mixer to reveal the inner parts.

Step 4 — Gear Housing Cover



- Remove the 4 Phillips #2 screws connecting the black housing cover to the device.
- ⓘ Only one of the screws is seen in the picture. The other three are also located around the black housing cover.

Step 5



- Take off the black housing cover.

To reassemble your device, follow these instructions in reverse order.

This document was last generated on 2017-11-18 03:20:55 PM.